



INSTALLATION INSTRUCTIONS
P/N 23750, 23760, 23700, AND 23710

Please read instructions thoroughly before installation.

This Oil Filter Mount is designed to hold Chevrolet-type spin-on oil filters. The filters listed below can all be used with it, depending on the amount of mounting space available.

STANDARD CHEVROLET SIZE – LENGTH 4 1/4”

Use Moroso P/N 22459

CHEVROLET TRUCK SIZE (ONE QUART CAPACITY) – LENGTH 5 1/2”

Use Moroso P/N 22460

CHEVROLET TRUCK SIZE (TWO QUART CAPACITY) – LENGTH 8 7/16”

Use Moroso P/N 22461

MOROSO #23700 AND 23710 REMOTE OIL FILTER MOUNT

This Oil Filter Mount is designed to hold Ford V-8 and some 6 cylinder Fords, and all Chrysler V-8 spin-on oil filters.

STANDARD FORD SIZE – LENGTH 5 1/4”

Use Moroso P/N 22470

Clean filter mount thoroughly before use.

The inlet, outlet and top center fitting holes all take 1/2” NPT fittings. All oil lines should be made up from hydraulic high-pressure hose with either a nylon or stainless steel outer cover and a 400 psi or better rating. Both inlet and outlet lines should have a minimum i.d. of 5/8” (-10 AN line).

The line running between the dry-sump pump pressure outlet and the remote oil filter mount should enter the mount only through the hole marked “IN”. Either the hold marked “OUT” or the top center hole can be used as the filter outlet. The outlet line should run from the remote oil filter mount outlet to an oil filter block-off plate. The outlet hole that is not used can be either blocked off or used to mount an oil-pressure gauge line.

When installing screw-on filter, be sure to coat oil filter gasket with a film of clean engine oil. Install filter and hand tighten until gasket contacts base. Then tighten three quarters of a turn more. **DO NOT OVER TIGHTEN.**

PARTS LIST

(1) Remote Oil Filter (1) Nipple

For Technical Assistance, Call Moroso’s Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC

80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906



INSTALLATION INSTRUCTIONS
P/N 23750, 23760, 23700, AND 23710

Please read instructions thoroughly before installation.

This Oil Filter Mount is designed to hold Chevrolet-type spin-on oil filters. The filters listed below can all be used with it, depending on the amount of mounting space available.

STANDARD CHEVROLET SIZE – LENGTH 4 1/4”

Use Moroso P/N 22459

CHEVROLET TRUCK SIZE (ONE QUART CAPACITY) – LENGTH 5 1/2”

Use Moroso P/N 22460

CHEVROLET TRUCK SIZE (TWO QUART CAPACITY) – LENGTH 8 7/16”

Use Moroso P/N 22461

MOROSO #23700 AND 23710 REMOTE OIL FILTER MOUNT

This Oil Filter Mount is designed to hold Ford V-8 and some 6 cylinder Fords, and all Chrysler V-8 spin-on oil filters.

STANDARD FORD SIZE – LENGTH 5 1/4”

Use Moroso P/N 22470

Clean filter mount thoroughly before use.

The inlet, outlet and top center fitting holes all take 1/2” NPT fittings. All oil lines should be made up from hydraulic high-pressure hose with either a nylon or stainless steel outer cover and a 400 psi or better rating. Both inlet and outlet lines should have a minimum i.d. of 5/8” (-10 AN line).

The line running between the dry-sump pump pressure outlet and the remote oil filter mount should enter the mount only through the hole marked “IN”. Either the hold marked “OUT” or the top center hole can be used as the filter outlet. The outlet line should run from the remote oil filter mount outlet to an oil filter block-off plate. The outlet hole that is not used can be either blocked off or used to mount an oil-pressure gauge line.

When installing screw-on filter, be sure to coat oil filter gasket with a film of clean engine oil. Install filter and hand tighten until gasket contacts base. Then tighten three quarters of a turn more. **DO NOT OVER TIGHTEN.**

PARTS LIST

(1) Remote Oil Filter (1) Nipple

For Technical Assistance, Call Moroso’s Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC

80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906



INSTALLATION INSTRUCTIONS
P/N 23750, 23760, 23700, AND 23710

Please read instructions thoroughly before installation.

This Oil Filter Mount is designed to hold Chevrolet-type spin-on oil filters. The filters listed below can all be used with it, depending on the amount of mounting space available.

STANDARD CHEVROLET SIZE – LENGTH 4 1/4”

Use Moroso P/N 22459

CHEVROLET TRUCK SIZE (ONE QUART CAPACITY) – LENGTH 5 1/2”

Use Moroso P/N 22460

CHEVROLET TRUCK SIZE (TWO QUART CAPACITY) – LENGTH 8 7/16”

Use Moroso P/N 22461

MOROSO #23700 AND 23710 REMOTE OIL FILTER MOUNT

This Oil Filter Mount is designed to hold Ford V-8 and some 6 cylinder Fords, and all Chrysler V-8 spin-on oil filters.

STANDARD FORD SIZE – LENGTH 5 1/4”

Use Moroso P/N 22470

Clean filter mount thoroughly before use.

The inlet, outlet and top center fitting holes all take 1/2” NPT fittings. All oil lines should be made up from hydraulic high-pressure hose with either a nylon or stainless steel outer cover and a 400 psi or better rating. Both inlet and outlet lines should have a minimum i.d. of 5/8” (-10 AN line).

The line running between the dry-sump pump pressure outlet and the remote oil filter mount should enter the mount only through the hole marked “IN”. Either the hold marked “OUT” or the top center hole can be used as the filter outlet. The outlet line should run from the remote oil filter mount outlet to an oil filter block-off plate. The outlet hole that is not used can be either blocked off or used to mount an oil-pressure gauge line.

When installing screw-on filter, be sure to coat oil filter gasket with a film of clean engine oil. Install filter and hand tighten until gasket contacts base. Then tighten three quarters of a turn more. **DO NOT OVER TIGHTEN.**

PARTS LIST

(1) Remote Oil Filter (1) Nipple

For Technical Assistance, Call Moroso’s Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC

80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906