



INSTALLATION INSTRUCTIONS
-12AN REMOTE ADAPTER KIT SB FORD
APPLICATION: JESEL BELT DRIVE KIT KBD - 34170
JESEL BELT DRIVE KIT KBD - 34175

P/N 63519

PARTS LIST

- | | |
|----------------------------|-----------------------------------|
| (1) Adapter Passenger Side | (4) 5/16-18 X 1.75 Stainless SHCS |
| (1) Adapter Driver Side | (4) 5/16-18 X 2.50 Stainless SHCS |
| (2) O-Rings | |

INSTALLATION

This remote –12AN Adapter Kit is made for our customers utilizing a remote water pump and an auxiliary radiator fan. The adapter is designed to fit with the Jesel SB Ford applications mentioned above.

1. Disconnect and remove the negative battery terminal from the battery terminal post for safety precautions.
2. Drain the fluid from the cooling system.
3. Remove the old timing cover and install your Jesel mounting cover if not already done so in accordance to Jesel's instructions.
4. Check and clean any old sealing material and O-rings where the Moroso adapters are going to mate.

NOTE: Lubricate the screw threads with oil prior to installation.

The (4) 5/16-18 X 1.75 screws supplied are used with Jesel's cover CVR 32715 and motor plate. The (4) 5/16-18 X 2.50 screws supplied are used the Jesel's mounting cover CVR 32710 and water pump standoff design.

5. Install new O-Rings supplied to Jesel's cover.
6. Install the new fasteners and torque to 11 ft-lbs and final torque to 15 ft-lbs.
7. Plumb the Remote Water Pump to the radiator and to the Moroso Adapters with –12AN fittings (not included).
8. Refill the coolant system and service the coolant system per manufacturers service manual.
9. Re-connect the negative battery terminal to its post.

Thank you for purchasing Moroso Performance Products.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev. A
082714

Visit Us At www.moroso.com

63519INST