



## INSTALLATION INSTRUCTIONS

**P/N 65847 - 5.0 MUSTANG COLD AIR INLET KIT**

### PARTS LIST

1 AIR INLET TUBE	4 WASHER
4 6 MM BOLTS	
1 FENDERWELL PLATE	
1 HOSE CLAMP	
1 AIR FILTER	

The Moroso Mustang Cold Air Inlet Kit is designed so that no cutting or modifications are required. The kit replaces the stock filter box and air silencer. Unlike ram air kits that ingest debris and water, along with causing clearance problems, the Moroso Cold Air Inlet Kit supplies the engine with cool air without the inherent disadvantages of mounting a scoop under the front fascia.

### SYSTEM INSTALLATION:

1. Remove the stock airbox and silencer. Remove all components, including the rubber isolators.
2. Insert the inlet tube through the matching slots in the fenderwell plate and rotate it 90°. Install the tube/plate assembly into the inner fender. Using the four supplied 6 mm bolts, fasten the plate to the fenderwell.
3. Slide the inlet tube into the stock rubber boot. Silicone spray makes the installation of the boot easier.
4. Mount the air filter on the end of the tube. The filter and clamp can be installed from underneath. There is room to tighten the clamp in the area between the fender and the inner fenderwell. The filter should be cleaned regularly in hot, soapy water using a mild detergent and can then be reused. Always re-spray the element with K & N air cleaner spray before installing.

**For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437-2116  
Phone: (203) 453-6571 • Fax: (203) 453-6906