



## CARBURETOR AIR PAN KIT

**P/N 65950**

### PARTS LIST:

- |                                    |                                |
|------------------------------------|--------------------------------|
| 2) Aluminum Pans with 5-1/8" holes | 4) 1/8" x 1/4" Long Pop Rivets |
| 1) Foam Strip 1-1/2" x 4" x 60"    |                                |

**NOTE: FOR DUAL 5 1/8" NECK CARBURETOR APPLICATIONS ONLY**

### Installation Instructions:

1. Place the two plates on your carburetor and mark where they overlap.
2. Using this mark as a guide, drill and pop rivet the two halves together.
3. Lay the foam strip inside the outer lip and measure the length needed.
4. Cut the foam to length and glue to pan assembly with weather stripping cement.

**For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437-2116  
Phone: (203) 453-6571 • Fax: (203) 453-6906