



## Center Bolt Aluminum Valve Cover

### ***Installation Tips:***

Clean Valve Covers thoroughly before installation.

Check clearance of valve-train components. These covers have been designed to fit over Moroso Center Bolt Stud Girdles, (see current Moroso Catalog for listing of available parts).

DO NOT OVERTIGHTEN. Torque the supplied SHCS and Washers to 20 in. lbs.

If you have purchased P/N 68025 and need to install a breather, drill a 1-3/16" hole and use a round file to increase the hole diameter to approximately 1.22" and to remove any flashing.

*Check the Moroso catalog for a selection of accessories for your new Moroso Valve Covers, such as replacement Breathers, PCV Grommets, Oil Filler Cap, and Crankcase Evacuation Systems.*

***For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

**MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • FAX (203) 453-6906**