



## FABRICATED VALVE COVER WITH POSITIVE SEAL FITTING

1. Clean opening of all burrs and debris.
2. Place the supplied flat Washer onto the AN Fitting and place this through the hole from the outside of the valve cover.
3. Install O-ring into the groove of the Venting Nut.
4. Screw the Nut into the AN Fitting hand tight.
5. Install the valve cover onto cylinder head with proper gasket and tighten securely.
6. Connect the proper length of AN hose from the Fitting to the Vacuum Pump Inlet.



Typical installation

***For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.A  
010307

Visit Us At [www.moroso.com](http://www.moroso.com)

68356INST