



Part # 68388 Ford Modular 3 Valve Cover

PARTS LIST

- | | |
|----------------------------|---------------------------|
| 1) Driver side valve cover | 1) Pass. side valve cover |
| 29) 6mm x 1.0 x 25mm SHCS | 29) 6mm SS Flat Washer |
| 1) PCV valve | 1) Hose connector |



Cut 15/16" off end of the plastic connector to use to adapt up to the hose size.

Make a cut 3-1/2" from the straight coupling end, and cut 1-1/8" section out of hose for inserting the PCV valve.

INSTALLATION

Note: Use Ford Valve Cover Gasket for 05-09 Mustang P/N 7L1Z-6584A (right), 7L1Z-6584B (left), and Cam Timing Seal Ford P/N 7L1Z-6C535AA

PCV hose modification: Remove foam wrapping from PCV hose. Cut the PCV hose 3-1/2" from the straight connection end (see diagram). Cut a 1-1/8" section out from the first cut (the PCV valve will take the place of this section of hose).

Cut the NAPA plastic hose connector 15/16" from the end (see diagram). This short piece with the barb will adapt up the PCV valve to the proper hose diameter. Using a heat gun, warm the barbed piece of the connector you removed and press it all the way on to the small end of the PCV valve.

The PCV valve will be inserted in-line of the hose with the flow direction arrows (stamped in the PCV valve) pointing toward the intake manifold (the small diameter end of the PCV valve is the end that points toward the intake).

Using a heat gun, warm the hose end with the straight coupling and press the PCV valve in all the way (up to the PCV valve shoulder).

Using the heat gun, warm the other half of the hose end and press in the PCV valve (end with the plastic barb adapter) all the way to the shoulder.

For Technical Assistance, call Moroso's Tech Line at

(203) 458-0542, 8:30am-5:00pm Eastern Time

80 CARTER DRIVE GUILFORD, CT. 06437 203-453-6571 WWW.MOROSO.COM