



## INSTALLATION INSTRUCTIONS

### NUMBERED SHRINK SLEEVE P/N 72020

1. Clean all surfaces that shrink sleeve will cover.
2. Use an electric hair dryer to apply heat to the shrink sleeve. Make sure to heat thoroughly, even after it has shrunk, so tubing will hold after it cools. Shrink sleeve should be HOT. While other methods of applying heat may be acceptable, (heat lamp, electric heater, etc.) **DO NOT USE AN OPEN FLAME!** Poor adhesion will certainly result, not to mention discoloration.
3. Moroso #72030 Shrink Sleeves are still needed to complete the seal between boots and spark plug wire at each end.

**For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

**MOROSO PERFORMANCE PRODUCTS, INC**  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906

**Visit Us At [www.moroso.com](http://www.moroso.com)**