



INSTALLATION INSTRUCTIONS
P/N: 85800,85810,85820,85850, & 85860
U-JOINT GIRDLES

PARTS LIST

2- Aluminum Caps
4- Nuts

4- Socket Head Cap Screws
4- Washers

*Note: Moroso P/N 85810 does not come with any washers.

Installation Notes

1. In some applications where original factory installed equipment included straps, it will be necessary to drill out the yoke to accept the through bolts.
2. When installing, be sure to press the clamp down on bearing cap and check for at least .010" crush at the parting line. Be sure to grind or file the yoke if needed-DO NOT GRIND ON THE CAP!
3. When the tightening the through bolts make sure the girdle comes down straight and not cocked over to one side.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

*MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906*