



INSTALLATION INSTRUCTIONS

P/N C3046

82-92 Camaro/Firebird Weld-in Frame Connectors

NOTE: Transmission Crossmember must be removed before installing Frame Connectors.

1. Place a Connector in position by lining up the frame connector holes with the bolt holes for the transmission crossmember.
2. Using the body/floor pan seam as a reference point, line the connector up so it is exactly parallel to the seam front to back.
3. Trace connector onto the floor pan from front to back.
4. Cut floor pan away where needed.
5. When the connector is lined up in all directions, hold it in place with transmission crossmember mount bolts. Then tack it into place and check all dimensions.
6. Weld the connector to the subframe wherever contact is made and to the floor pan where possible.
7. Repeat this procedure for other side.

*For Technical Assistance, call Competition Engineering's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time*

COMPETITION ENGINEERING
Carter Drive • Gullford, CT 06437
Phone: (203) 453-5200 • Fax: (203) 453-6906

Visit Us At www.competitionengineering.com