



INSTALLATION INSTRUCTIONS

P/N: C7046

BOLT-ON WHEEL-E-BAR CONVERSION KIT

These Bolt-on Wheel-e-bar Conversion Brackets replace the existing axle mounting brackets found in Competition Engineering Wheel-e-Bar Kits P/N's C2016, C2039, and C2040.

Installation

Bolt the new brackets to your wheel-e-bar using the original fasteners provided. With the car on a level surface, position the wheel-e-bars under the car with the brackets resting up against the housing. Then prop them up so the wheels are 6" off the ground for street use. In this position, fasten the housing saddle brackets over the rear end housing using the 1/2-20 Nylock nuts provided.

If the rear end housing brackets are too big for your particular housing, the housing saddle bracket can be welded to the housing and the rear end bracket bolted to it. Thereby allowing the wheel-e-bars to be removed from the car.

Note: The Axle Housing must be clean and free of welding slag, etc. in the vicinity where the housing brackets will be located to insure a firm grip of the bracket and strap on the housing.

*For Technical Assistance, call Competition Engineering's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time*

COMPETITION ENGINEERING
80 Carter Drive • Guilford, CT 06437
Phone: (203) 453-5200 • Fax: (203) 453-6906

Visit Us At www.competitionengineering.com