

**27249**  
**MAGNETIC PICKUP**  
**INSTALL INSTRUCTIONS**  
**1-14-09**

1. REMOVE OLD UNIT.
2. APPLY A SMALL AMOUNT OF "MEDIUM" THREAD LOCK TO THE THREADS OF THE SCREWS THAT SECURE THE PICKUP TO THE DIST.
3. LOOSELY BOLT IN NEW UNIT, VERIFY MAGNET HAS THE SOUTH POLE FACING UP.
4. **SET AIR GAP BETWEEN RELUCTOR AND PICKUP TO .030"**
5. TIGHTEN SCREWS, INSTALL PLUG FROM THE MAGNETIC PICKUP ONTO THE CONNECTOR ON IGNITION MODULE.
6. **SET ENGINE TIMING!**