



Tire Pressure Gauge

You have purchased an extremely fine and sensitive gauge that is designed to give accurate readings. Since this gauge has a very delicate mechanism, great care should be taken not to drop, dent or otherwise abuse it.

Operating Instructions

- (1) To use this gauge, hold gauge head in a vertical position for the most accurate reading possible. Place on tire valve and note reading.
- (2) If the tire pressure is higher than desired simply press bleed button (located on the hose just below the gauge head) until desired pressure is reached.

Caution: The No.89581 Gauge is designed to be used on tires containing no more than 15 P.S.I. over pressurization will severely damage gauge.

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906