



Installation Instructions

P/N's: 97515, 97517

Air Filter Element Oiling Instructions

NOTE: We recommend using S&B air filter oil P/N 6002 or K&N filter oil P/N 99-0504 or 99-516.

WHEN THE FILTER ELEMENT IS USED IN A DRY MODE

- The filter can be cleaned with compressed air blown from the inside out. (Always wear eye protection).
-

WHEN THE FILTER ELEMENT IS USED IN A WET (OILED) MODE

- Tap the element against a hard surface (Be careful not to damage the pleated element material).
- Lightly brush heavily soiled areas with a fiber bristle brush.
- Agitate filter element in ½" of hot water and laundry detergent, dish washing soap, or a non-flammable industrial cleaner. (Do not use fuels). After soaking element, let stand for five (5) minutes.
- Using a water hose, rinse element from inside out, with low pressure
- After drying, apply air filter oil to element, making one pass around. The oil should completely cover all pleats without dripping from the element. Let the element stand for approximately 15 minutes to allow the oil to soak into the element material.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906